


Water Blaster (3000psi)

Operating and Safety Instructions

If you are collecting the equipment for someone else please make sure this sneet is given to the equipment user to read. In accordance with Health and Safety in Employment Act requirements, this sheet should be given to the site supervisor if the equipment is being hired for use at a commercial worksite so that the information is available to all users.



Required Safety Equipment



Pre-Start Checks and Safety

- ! Maximum towing speed is 90km/hr
- ! Fuel tank is full (straight petrol or diesel)
- ! Engine oil is at correct level
- ! Check oil level in pump and reduction box
- ! Ensure adequate water supply is available
- ! Suction filter is clean
- ! Avoid kinks in suction and delivery hoses
- ! Remove trailer unit from tow vehicle before use and place on jockey wheel / stand to keep level. Chock wheels if required
- ! Never run machine without water
- ! Never spray at people or animals
- ! Never hold fingers or hands over high pressure nozzle
- ! Never spray directly onto live electrical equipment

When Operating

- Adjust throttle to the full position
- Depress trigger on gun and commence cleaning
- Never allow machine to run out of water
- Never point spray gun outlet at people

Starting procedure

- Connect water hose to blaster storage tank
- Unwind enough pressure hose from trailer unit to move around required area
- Turn on water supply and allow storage tank to full
- Leave water turned on
- Turn on fuel supply
- Adjust throttle to ½ throttle
- Choke engine for cold start on petrol models
- Turn key to glow position and hold for 20 seconds on diesel models
- Turn ignition switch and start
- Return throttle to idle position and allow to warm up

Stopping and After Use

- Switch off machine
- Turn off fuel
- Depress trigger on gun to allow the pressure to be released
- Disconnect all hoses and roll up