

Operating and Safety Instructions

CHIPPER HYDRAULIC FEED – 150MM Petrol

USES Chipping Brush & Tree prunings



PRE CHECK

Check fuel tank is full (Petrol)
Check engine oil level
Feed and discharge shoots clear



STARTING

Level machine and engage leveling leg at rear of chipper
Fold inlet chute down and lock in place
Ensure feed roller control lever (red) is in stop position
Move throttle lever to half throttle
Pull the choke throttle out all the way and then turn ignition key on. Warm engine for 2 minutes and then move to full throttle



OPERATION

OBSERVE ALL SAFETY DECALS ON THE MACHINE

Pull feed roller lever gently towards you to the feed position. Feed branches into inlet chute. If branches get stuck move lever to reverse.



STOPPING

Move throttle lever to idle position
Allow engine to idle down. Push STOP button. Turn ignition switch to 'OFF' (vertical).



SAFETY PRECAUTIONS AND EQUIPMENT

Use only a wooden article to push material into the shredder hopper.
Do not use bare hands - always wear gloves to handle branches etc.
Do not overload. Should an overload occur - stop machine – open top cover, clear around rotor and outlet chute before restarting.
Keep other people away from area especially children.
Do not attempt to make any clearance with your hands or any object while unit is running.
Necessary for personal safety: Goggles, Gloves, Ear muffs, Strong Footwear.



HAZARDS

The removal of any guards.
The clearing of blockage with hands while unit is running.
Wire, steel, stones, bamboo, flax or other stringy foliage .

Personal Protective Equipment

